

# INSTALLATION INSTRUCTIONS



## 1279 - TO SUIT AUDI 80 7/92-ON

### PLEASE READ INSTRUCTIONS THROUGH BEFORE YOU BEGIN

**WARNING :** 1. Do not drill, cut weld or otherwise modify the towbar.

2. If you are using electric welding on a motor vehicle, always check that the vehicle is not equipped with electronic engine or instrument management equipment. Failure to do so could destroy any onboard computers. If in doubt, check with the vehicle's manufacturer.

1. Ensure all hardware items have been included.
2. Remove bumper.
3. Remove tape covering 6x8mm taped holes 3 each side.
4. Hold towbar up against rear panel and align holes in towbar with taped holes.
5. Fit 6x8mm bolts supplied and tighten.
6. Fit 2x12mm bolts, one each side, through hole in body with loose plate inside boot.
7. Using two remaining holes as guides drill 13mm holes through body and fit bolts.
8. Tighten bolts as per torque listing below.
9. Slide bumper back into position as far as possible so edge of bumper hits saddle dropper. **NOTE: Cutting of bumper may be required on some models.**
10. Mark bumper either side of dropper.
11. Remove bumper and cut as per sketch **NOTE: Centre bumper support arm may have to be cut.**
12. Towbar rating sticker to be conspicuously located on inside rear end of the drivers door. (see diagram below)

### RECOMMENDED ASSEMBLY TORQUE LISTING


<u>Diameter</u>	<u>Grade 4.6 Bolt</u>	<u>Grade 8.8 Bolt</u>
	Nm	Nm
M6	3.5	9.5
M8	8.6	21.7
M10	16.9	43.4
M12	29.8	77.3
M16	74.0	189.8

#### **FOR TOWING PURPOSES ONLY**

For towing capacity details please refer to vehicle owner's manual or to the manufacturer. Overloading can void your warranties

**PLEASE NOTE:** You must remove the lug unless you are actually towing if it obscures your number plate. Failure to do so may result in a fine.

**IMPORTANT:** Please see over for safety chain hook-up procedure.



**1279 - TO SUIT AUDI 80 7/92-ON**